



1. Drill plastic out of the mounting holes with a  $\frac{7}{16}$ " dia. drill bit.
2. Position bike rack where desired.
3. Secure to the surface with the appropriate fasteners.